

Tension of the spring mechanism



Remove the top lid by unscrewing the top two screws from the left and right sides.



Carefully remove the leader from the roll.



Unfold the stabilising foot. Place the palms at the outer ends of the roll. Tension the spring mechanism 30 turns by sliding your palms forward.



Make sure the adhesive on the roll is facing up and lock the spring mechanism with the locking pin.

Graphic No. 11340



Replace the leader on the roll over the existing adhesive and press firmly.



Apply packing tape over the joint if necessary.



Replace top lid and tighten the screws on both sides. READY!

Graphic No. 11340